

## 2K-Aqua Hardener 2380



Special hardener for 2K-Aqua Silk Matt Enamel 2388, 2K-Aqua Matt Enamel 2390, 2K-Aqua Durakett 2394 and 2K-Aqua Whiteboard 2384

### Field of application

For mixing with 2K-Aqua Silk Matt Enamel 2388, 2K-Aqua Matt Enamel 2390, 2K-Aqua Durakett 2394 and 2K-Aqua Whiteboard 2384.

### Properties

Special system hardener. The container sizes reflect the mixing ratio.

### Material description

<b>Color</b>	Colorless
<b>Base material</b>	Aliphatic polyisocyanate
<b>Flash point</b>	> +61°C
<b>Density</b>	Approx. 1.09–1.13 g/cm <sup>3</sup>
<b>Packaging</b>	125 ml of hardener for 875 ml or 625 ml of base material 500 ml of hardener for 3.5 liters or 2.5 liters of base material (Base enamel and hardener are supplied separately)

### Use

<b>Mixing</b>	Before adding the hardener, thoroughly stir the 2K-Aqua Silk Matt Enamel 2388, 2K-Aqua Matt Enamel 2390, 2K-Aqua Durakett 2394 or 2K-Aqua Whiteboard 2384 until even. Mix the base component and hardener in the specified mixing ratio shortly before application. Ensure that the hardener container is completely emptied without residue. Follow the instructions on the 2K-Aqua Silk Matt Enamel 2388, 2K-Aqua Matt Enamel 2390, 2K-Aqua Durakett 2394 or 2K-Aqua Whiteboard 2384 data sheets.
<b>Compatibility</b>	Can only be mixed with materials specified in this data sheet.
<b>Application temperature</b>	Do not apply at temperatures below +8°C or above a max. of +25°C air, substrate and material temperature. Take the dew point temperature into consideration. Do not apply unless the temperature is at least 3°C above the dew point.

## Use

**Tool cleaning** Clean tools with water and wetting agent immediately after use.

## Storage

Store in a cool, dry and frost-free place. Reseal opened containers tightly.

## Declaration

**Product code** PU30.  
Comply with the specifications in the current safety data sheet.

## Notes

**Further information** Follow the instructions in the data sheets of the products used.

## Remark

This data sheet is based on extensive development work and years of practical experience. The translation corresponds to the current German version, in compliance with the German laws, regulations, standards and guidelines. Its content does not constitute a contractual legal relationship. The user/buyer is not released from the responsibility of checking our products to ensure they are suitable for the intended application. In addition, our general terms of business apply.

When a new version of this data sheet with updated information is published, the previous version no longer applies. The current version is available on our website.

Brillux  
Weseler Straße 401  
48163 Münster  
GERMANY  
Phone +49 251 7188-0  
Fax +49 251 7188-105  
info@brillux.de  
www.brillux.com